



Instruction Booklet 사용설명서



750W TOURMALINE CERAMIC IONIC HOT AIR STYLER 750W 토크말린 세라믹 이온 에어 스타일러

VSAS80PIK



VS SASSOON 750W TOURMALINE CERAMIC IONIC HOT AIR STYLER

Your new hot-air brush comes with 3 accessories, each one indispensable for reproducing your hair stylist's creations at home.

Airstyle 750 is the ideal tool for creating your blow-dry look and all the trendiest styles.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children. Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.



1. If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
2. Never immerse the unit in water or any other liquid.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. When using the unit, make sure the unit's air vent is not blocked. Make sure there is no hair or any other dirt obstructing the unit's rear filter.
5. This unit has been equipped with a temperature cut-out. If the unit overheats, it will shut off automatically or will stop heating. If this happens, slide the switch on the unit's handle into the OFF position, unplug the unit and allow it to cool for 10 minutes. BEFORE using it again, make sure there is no hair or any other dirt in the unit's rear filter. Plug the unit in and switch it on. If it overheats again, stop using it immediately, switch it off and unplug it. Return the unit to the VS SASSOON service centre.
6. Do not use the unit if it has fallen or if it appears to be damaged.
7. Do not leave the unit unattended when it is plugged in or switched on.
8. Unplug the unit immediately if you have problems when using it.
9. Do not use any accessories other than those recommended by manufacturer.

10. Unplug the unit after each use and before cleaning it.
11. Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
12. This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
13. Allow the unit to cool before storing.
14. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.

FITTING AND REMOVING THE ATTACHMENTS

Fit the brushes onto the body of the unit by lining up the guides on the two parts and then press the two together until you hear a click.

INSTRUCTION FOR USE

The brush has 3 settings: 0 (off), ★ (cool), I (low) and II (high). The low setting is ideal for fine hair, the high setting for thicker hair.

The cool position lets you to fix the styling for really long-lasting effects.

Use your hot-air brush on pre-dried, slightly damp hair that is completely tangle free.

Use clips to separate hair so that you can work on one section at a time. Start with the sections underneath. Sections should be a maximum of 2cm wide and as even as possible. Always work from the roots to the tips and slide the brush slowly down the length of the section.

Then take small sections of the hair, and curl it with the 38mm barrel of the hot air brush.

THE 38MM DIA TOURMALINE CERAMIC COATED THERMAL BRUSH

For perfect glide and to offer your hair better protection. The combination 'brush/hair dryer' will revolutionise your blow drying!

This ideal diameter, recommended by VS SASSOON, creates a smooth movement and adds body to your hair without tangling it and for the best blow-dry results for hair full of softness.

The hot air of the unit heats the metal barrel of the attachment. The heat is thus distributed directly over your hair making it soft and smooth.

PADDLE BRUSH

Place the brush under hair, close to the roots. Slide it down to hair ends. This will give perfect shape to your hair style.

THE TOURMALINE CERAMIC COATED STRAIGHTENING COMB

The ergonomic single straightening head of airbrush makes it especially easy to use: hair dried and straightened from roots to tips in just on stroke!

The one row of teeth let you straighten twice in just one

stroke for greater efficiency and speed. The Tourmaline Ceramic coating provides perfect glide through your hair and guarantees perfect straightening, while completely respecting the hair.

Tensio Control System® 4 settings: 1. waves, 2. loose curls, 3. tight curls, 4. very tight curls

There are 4 fundamental types of curls (waves, loose curls, tight curls, very tight curls). Its experience today brings to VS SASSOON brushing an unequalled performance thanks to the Tensio Control System®. This patented technology can adapt to every type of curl, providing the right tension for perfect straightening: no more tugging and tearing hair during laborious blow-drying!

GET TO KNOW YOUR 750W TOURMALINE CERAMIC IONIC HOT AIR STYLER



TOURMALINE CERAMIC TECHNOLOGY

The Tourmaline Ceramic Technology features crushed tourmaline gem stone crystals infused with ceramic. Tourmaline emits negative ions which dramatically reduce drying time and static electricity. Ceramic emit far infrared heat providing a gentle, even heat that is less damaging. The

results are unsurpassed; faster, healthier drying with shiny, smooth results.

IONIC TECHNOLOGY

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution contribute to a build-up of static electricity in the hair. Even brushing and towel drying the hair, can increase these levels causing the surface of the cuticle to become rough. Consequently, hair may have a dull appearance. High levels of static charge cause hair to become "fly-away" and difficult to style. The ion generator in this dryer produces a stream of negative ions which act to neutralise the static charge, smoothing the scales on the cuticle for shiny, smooth and manageable hair so you can achieve your desired style easily.

GENERAL

After use, switch off and unplug the appliance. Allow to cool before storing away.

CLEANING & MAINTENANCE

The rear filter should be cleaned, using a soft brush, on a regular basis to help prevent the ingress of hair and other debris into the internal components

USER MAINTENANCE

Your styler is virtually maintenance-free. No lubrication is needed. For proper operating performance, the styler must be kept clean. **Blocked or clogged air intake vents will cause the styler to overheat.** When cleaning is needed, unplug the cord, and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the styler should be wiped clean with a damp cloth only.

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the styler. Damage will occur at the high flex point of entry into the styler, causing it to rupture and short. Inspect the cord frequently for damage, **stop use immediately if damage is visible or unit stops or operates intermittently.** If the cord or styler is damaged or does not operate properly, return it for repair to the VS Sassoon Service Centre. No repairs should be attempted by the consumer.

STORAGE

when not in use, your styler should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around styler.

THE DATE CODE MENTIONED

WWYYXXX was mentioned on unit as manufactured date so you can see W as week and Y as year for your reference.



CONTINENTAL CONAIR LIMITED CHINA CREATIVE DEPARTMENT

Date	1/18/2021
Customer	VS-KOREA
Model No.	VSAS80PIK
Description	IB
Job No.	
Reference No.	IB-11/164N
Revision No.	0
Color	1C+1C(Black)
Open Size	552mm(W) X 214mm(H)
Folded Size	92mm(W) X 214mm(H)
Material	80gsm Artpaper
Prepared by	Betty bai
Approved by	Ken Xiong/Francesca Seo
Vendor	Silverplan
Supplier	

折叠方法
Folding method:
12 pages (6 x 2)



수입 판매원

콘에어코리아트레이딩주식회사

소비자상담실 : 1899-0209

A/S센터 : 자사의 A/S대행업체인 필일렉
www.fillelec.co.kr의 홈페이지를 통해서 가가
운 A/S센터(전국 38개점)를 확인하세요

Conair Korea Trading Limited

www.vidalsassoon.kr

Certain trademarks used under license from The Procter & Gamble Company or its affiliates.

VSAS80PIK

IB-11/164N

VIDAL SASSOON 750W 음이온 핫 에어 스타일러
 새로운 핫에어 브러쉬는 3개의 액세서리 가 있으며 각 각의 전문화된 부품을 사용하여 집에서든 전문가 수준의 스타일링 연출이 가능합니다. 에어스타일러 750은 볼륨 드라이연출 과 최신 헤어스타일을 연출을 위한 가장 이상적인 제품입니다.

주요 안전 주의사항

제품 사용 시 특히 어린이가 있을 경우 다음의 안전 주의사항을 반드시 준수하여야 합니다.

사용 전 반드시 사용설명서를 숙지하여 주십시오. 물에 접촉하거나 빠뜨리시면 안됩니다.

안전주의

경고: 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용할 경우 위험할 수 있습니다. 어린이의 손이 닿지 않도록 주의해 주십시오. 이 포장재를 유아용 침대 혹은 요람 등에서 사용하지 마십시오. 얇은 필름으로 인해 유아가 질식될 수 있습니다.



경고: 이 제품을 욕조, 샤워기, 개수대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.



- 부득이 물이 있는 곳에서 사용하실 경우 사용 후 반드시 플러그를 뽑아 주십시오. 전원 스위치가 꺼져 있더라도 물 근처에서 사용하지 마십시오. 보다 안전한 사용을 위하여 육질의 잔류전류 용량은 30mA이하여야 합니다. 육질 등에서 사용 시 위 사항을 참조하여 전문가와 상의하시기 바랍니다.
- 물 또는 액체에 절대로 빠뜨리시면 안 됩니다.
- 전원코드가 손상되었을 경우 A/S 센터에서 반드시 수리를 받으셔야 안전합니다.
- 제품 사용 시 제품의 통풍구가 막히지 않았는지 확인 후 사용하십시오. 또한 제품 후면의 흡입구가 먼지나 머리카락으로 인해 막혀있지 않은지 확인하신 후 사용하십시오.
- 본 제품에는 온도 휴즈가 장착되어 있습니다. 만약 제품의 온도가 지나치게 상승하게 되면, 온도 휴즈에 의해 자동으로 전원이 꺼지게 되거나 열이 더 이상 공급되지 않게 됩니다. 이와 같이 자동으로 꺼지는 일이 발생할 경우는 스위치를 끄시고 전원코드를 뽑으신 후 흡입구가 먼지나 모발에 의해 막히지 않았는지 확인하시고 약 10분 정도 기다리신 후 다시 사용하시기 바랍니다. 플러그와 스위치를 다시 작동시키신 후 사용해 보시고 이런 일이 다시 발생할 경우 즉시 사용을 중단하시고, A/S센터에 연락하십시오.
- 제품을 떨어뜨리거나, 제품이 손상된 것처럼 보일

- 경우 사용을 중단하시고 A/S센터에 연락하시기 바랍니다.
- 전원을 연결하거나 스위치를 켜 상태에서 제품을 보관하지 마십시오.
 - 제품 사용 중 문제가 있을 경우 즉시 플러그를 뽑아 주십시오.
 - 제조업체가 공급하는 부속품 외의 부속품을 사용하지 마십시오.
 - 제품 사용 후나 제품 세척 전에 반드시 플러그를 뽑아주십시오.
 - 피부, 특히 귀, 눈, 목 등을 제품의 뜨거운 열판 사이에 닿지 않도록 각별히 주의하셔야 합니다.
 - 본 제품은 영,유아, 어린이, 심신 약약자, 심신 상실자, 정신 질환자 등에 의해 사용되어서는 안 되며, 사용 시에는 반드시 보호자의 보호가 필요합니다. 특히 어린이가 장난감처럼 사용하지 않도록 각별히 보호해 주십시오.
 - 제품 보관시 반드시 제품을 식혀 주십시오.
 - 전원코드의 손상을 막기 위해 꼬거나 구부러져 보관하지 말아 주십시오.

부속품 결합 과 분리

브러쉬를 본체에 결합하고자 할 때는 제품의 안내선에 본체와 브러쉬를 잘 맞추시고 클럭 소리가 날 때까지 힘을 주어 눌러주십시오.

제품 사용 용도 설명

- 3단 조절 셋팅: 꺼짐 (off), 냉풍 (cool), 약풍(약풍), 강풍(강풍)
- 약풍: 가늘고 힘없는 모발용/ 강풍: 두꺼운 모발용.
- 쿨버튼: 스타일 후 뜨거워진 모발을 식혀 스타일링을 오래도록 유지하는 용도.
- 핫 에어브러쉬: 젖은 모발부터 건조한 모발 까지 사용가능.

사용 설명서

- 보다 용이한 스타일링을 위해 적당량의 모발을 움켜잡니다
- 움켜잡힌 머리를 모근 가까이부터 드라이하며, 모발 끝까지 브러쉬 합니다.
- * 팁: 머리 술이 적은 경우 머리를 숙인 후 아래에서부터 위의 방향으로 브러쉬 하여 드라이 하거나, 가르마 반대방향으로 드라이 하시면 풍성한 볼륨 감의 연출이 가능합니다.
- 어느 정도 헤어 스타일이 정리 되면 정수리 부분에 마지막으로 38mm 라운드 스타일링 브러쉬를 이용하여 모발을 세우도록 합니다.
- 마지막으로 앞머리나 옆머리에 곁을 말아서 정돈 하도록 합니다.

38MM 스타일링 브러시

본 제품은 보다 편리한 모발 건조 및 스타일링을 위해 드라이어와 스타일링용 라운드 브러시가 결합된 혁신적인 제품입니다. 모발의 엉킴 없이 부드러운 스타일 드라이가 가능하도록 디자인 되었습니다. 브러시의 금속 플레이트는 뜨거운 공기에 의해 예열 됩니다. 적당한 온도로 예열된 브러시는 모발에 직접 열을 전달하여 스타일링을 가능하게 하고, 매끄럽고 부드러운 모발을 유지시켜 줍니다.

패들 브러시

브러시를 두피쪽부터 끝까지 브러싱하며 빗질하듯 사용합니다. 드라이 및 자연스러운 스타일링 연출이 가능합니다.

볼륨 매직 브러시

인체공학적 디자인의 볼륨 매직 브러시는 사용이 간편합니다. 모발의 건조와 동시에 뿌리부터 끝까지 자연스럽게 모발을 펴줍니다. 토르말린 세라믹 코팅은 미끄러지 듯 부드럽게 펴주는 동시에 모발을 보호합니다.



TOURMALINE CERAMIC 공법

토르말린 세라믹 공법은 토르말린 보석을 갈아서 세라믹과 결합 시킨 기술입니다. 토르말린은 음이온을 발생하여 획기적으로 드라이 시간을 단축 하고 정전기발생을 줄여줍니다. 세라믹은 원적외선을 방출하여 부드러운 열풍으로 모발의 손상을 줄여줍니다. 그 결과 탁월한 성능으로 모발을 가장 빠르게 건조하고 윤기있고 부드럽게하여 좀더 건강하게 유지할수 있도록 도와 줍니다.

이온기술

현대 환경에는 에어컨, 인조섬유, 오염된 공기 등으로 인해 발생하는 정전기로 인해 모발에 영향을 줄 수 있는 요인이 많습니다. 심지어 빗질을 하거나 타월로 모발을 건조하여도 모발의

표피와 표면을 거칠게 할 수 있습니다. 따라서, 모발에 심한 손상을 초래 할 수 있습니다. 또 높은 수준의 정전기는 모발을 날리게 하여 스타일 연출을 어렵게 합니다. 음이온은 모발의 정전기를 중화 시켜 모발의 표면을 매끄럽고 부드럽게 하고 윤기 있는 모발로 연출하여 쉽게 원하는 헤어스타일 연출을 도와 줍니다.

사용상식

사용 후 반드시 전원을 차단하고 플러그에서 분리한 후 차가운 상태로 보관합니다.

청소 및 유지 관리 사항

후면의 필터는 반드시 청결 하여야 합니다 부드러운 브러쉬를 사용하여 정기적으로 청소하여 모발이나 다른 이물질의 내부 유입을 방지 하십시오.

사용자 주의 사항

제품은 별도의 유지보수를 필요로 하지 않습니다. 윤활유 첨부를 필요로 하지 않습니다. 적절한 사용을 위해서는 드라이기는 반드시 깨끗한 상태로 유지 하여야 합니다. 차단된 또는 막힌 공기 투입구는 드라이 시 과열에 원인이 됩니다. 청소가 필요한 경우, 전원을 차단 하고 에어 투입구를 개봉 후 작은 브러쉬를 이용하여 먼지와 이상 물질을 제거 하도록 합니다. 드라이어의 다른 측면의 표면은 젖은 천으로 닦아서 청소합니다.

위험

절대로 전원 공급 장치 코드를 잡아 당기거나 꼬거나 또는 말지 마십시오. 절대로 코드를 제품 주위에 말지 마십시오. 제품의 손상의 파열은 구부러지거나 잘려지는 데서 시작 됩니다. 코드에 대해 손상되었는지 자주 검사 하도록 합니다. 코드의 구부림과 단선은 제품 손상 및 파열의 주요 원인이 됩니다. 만일 코드 또는 드라이어가 파손 또는 작동이 잘 되지 않을 시에는 비달사온 서비스 센터로 연락하시어 수리 하십시오. 소비자가 직접 제품을 수리하려 시도하지 마십시오.

보관

사용을 하지 않을 때 에는 반드시 안전하게 전원을 분리하고 아이들의 손에 닿지 않는 곳에 보관합니다. 코드로 제품 주위를 돌려 서 말지 마십시오.

제조일 표기

제조일은 본제품에 WWYYXXX 형태로 표기되어 있습니다. W는 '몇 째 주', Y는 '몇 년도' 를 나타냅니다.

제품 품질 보증서

성명	
전화번호	/휴대폰번호
e-mail	
주 소	
구입일자(년/월/일)	
모델번호(사용설명서 앞면 표기)	
대리점명(구입처)	

■ 주의사항

- 서비스를 받고자 하실때는 이 보증서와 구입 영수증을 제시하여 주십시오.
- 제품 구입일자가 고쳐지거나, 지워졌을 경우에 본 보증서는 무효입니다.
- 이 보증서를 분실하실 경우, 재발행되지 않습니다.

본 보증서는 보관하십시오

■ 품질 보증의 조건

- 본 제품의 품질보증 기간은 구입 일자로부터 2년간 입니다.
- 일상적인 사용에 의한 제품의 마모나, 마멸 또는 천재지변에 의한 제품의 손상 및 사용 설명서 상의 주의사항을 따르지 않고 임의로 사용하거나, 취급부주의로 인한 고장 등에 대해서는 본 보증서에 의한 무상 서비스를 받을 수 없습니다.
- 품질 보증서 상의 보증기간 내에는 제조상 또는 재질상의 결함으로 발생한 불량 등 에 대하여 무상 서비스를 받을 수 있으며 폐사의 판단에 따라 부품의 교환 또는 제 품의 교환도 가능합니다.
- 본 보증서의 효력은, 품질 보증서와 보증 등록서상의 대리점의 판매 확인과 제품구 입 후 4주 이내 보증등록서가 고객 서비스 센터에 우송 되었을 때로부터 발생 합니 다.
- 본 제품 품질보증은 수입판매원의 관할 이외 지역과 적법하게 위임 받지 않은 판매 처의 보증일 경우 효력을 상실합니다.

서비스를 받으시고자 할 경우 보증서의 내용을 기록하여 제품과 함께 보내주십시오

수입 판매원
 콘에어코리아트레이딩주식회사

소비자상담실 : 1899-0209
 A/S센터는 자사의 A/S대행업체인 필일렉 www.fillelec.co.kr의 홈페이지를 통해 서 가까운 A/S센터(전국 38개점)를 확인하세요